

Dresser

900000122



leeftijd
age **3+**

Let op: bestudeer deze bouwhandleiding zorgvuldig vóór montage. Montage alleen door volwassenen. SVP deze informatie bewaren ter referentie.
NOTE: Please read instructions before starting to assemble. Adult assembly required. Please retain this information for reference.

<p>A</p> <p>X1</p>	<p>B</p> <p>X1</p>	
<p>C</p> <p>X1</p>	<p>D</p> <p>X1</p>	<p>E</p> <p>X1</p>
<p>F</p> <p>X1</p>	<p>G</p> <p>X1</p>	<p>H</p> <p>X1</p>
<p>I</p> <p>X1</p>	<p>J</p> <p>X2</p>	<p>K</p> <p>X1</p>

<p>L</p> <p>X1</p>	<p>M</p> <p>X2</p>	<p>N</p> <p>X1</p>
<p>O</p> <p>X2</p>	<p>P</p> <p>X2</p>	<p>Q</p> <p>301327 M4x20</p> <p>X2</p>
<p>R</p> <p>360378 M4x20</p> <p>X7</p>	<p>S</p> <p>367134 M6x31</p> <p>X3</p>	<p>T</p> <p>301931 M6x22</p> <p>X4</p>
<p>U</p> <p>304267 M4x37</p> <p>X8</p>	<p>V</p> <p>367135 φ15x9.5</p> <p>X3</p>	<p>W</p> <p>X1</p>
<p>X</p> <p>X1</p>		

